

# How do I reset the PCB board?

In case you have trouble with your unit, see following diagram for the steps to follow in order to reset your PCB board.

Function	Action	Results
Test/demo	Push and release for no more than 5 seconds, when the motor is "OFF" or "ON".	The system performs self test, so the LED will light though all states.
Partial reset	Push and hold for more than 5 seconds, when the motor is "OFF".	The system will reset the 15 hours timing, if the system was blinking in the current color becomes solid.



Reset switch

# Comment réinitialiser le circuit imprimé?

Voici un tableau vous expliquant comment redémarrer votre circuit imprimé de votre unité.

Fonction	Action	Résultats
Test/démo	Appuyez et relâchez pendant 5 secondes (maximum) lorsque le moteur est éteint ou allumé.	Le système effectue un test automatique, de sorte que le voyant s'allume dans tous les modes.
Réinitialisation partiel	Appuyez et maintenez pendant plus de 5 secondes lorsque le moteur est éteint.	Le système réinitialisera le chronométrage de 15 heures. Si le système clignotait, la couleur actuelle devient unie.



Interrupteur de réinitialisation