

Why are the lights changing?

See the board below for details on when and why the LED light would change color.

Time used	LED color	Meaning	Action to be taken
15 hours	Slow blink	The vacuum must be full of debris.	Clean the bag and reset by holding this switch for 5 seconds.
0-449 hrs	Green	The vacuum has been used for less than 450 hours.	Vacuum is fully functional.
450 to 499	Amber	The vacuum has been used for more than 450 hours and less than 500 hours.	Service must be done. See warranty details
More than 500	Red	The vacuum has been used for more than 500 hours.	Service Now - See warranty details. Stop using vacuum to avoid breaking the motor.



Pourquoi la couleur de la lumière change?

Voici un tableau explicatif sur "quand et pourquoi" la lumière DEL change de couleur.

Temps d'utilisation	Couleur DEL	Signification	Action à faire
15 heures	Clignotant lent	L'aspirateur doit être rempli de débris.	Nettoyez le sac et réinitialisez le en maintenant cet interrupteur pendant 5 secondes.
0-449 heures	Vert	L'aspirateur à été utilisé moins de 450 heures.	L'unité est 100% fonctionnelle
450 à 499 heures	Ambré	L'aspirateur à été utilisé plus de 450 heures et moins de 500 heures.	La maintenance de l'unité doit être faite. - Voir les détails de garantie
Plus de 500 heures	Rouge	L'aspirateur à été utilisé plus de 500 heures.	Faire la maintenance immédiatement. - Voir les détails de garantie Arrêtez son utilisation immédiatement pour éviter d'endommager le moteur.

